



TECHNICAL DATA SHEET

Order reference	SPC818-E
Article number	813773

Date	6-29-06	Replaces	7-14-03	No. Pages	1
-------------	---------	-----------------	---------	------------------	---

Product Description:

Style	20 cm Bilge Boom - Large
Item Size (each)	45 cm long
Color	White
Composition	>95% Polypropylene; <5% Nylon (netting); metal staples, rings, & clips
Structure	Sorbent fill: Micro-fibrous meltblown polypropylene (2-10 micron diameters) <u>Inner covering:</u> Spunbond polypropylene nonwoven (15-30 micron dia. Fiber) <u>Outer covering:</u> Knitted Polyester yarn netting. <u>Inter-Connectors & Fasteners:</u> Breach clip; Ring; Tipper-Tie closures.
Technology	Meltblown; Lint-Resistant Spunbond
Absorbency	Hydrophobic + Oleophilic

Intended Application	Chemical Resistant "Lint Free" Sorbent Bilge Boom (large) for Spills of Oil Base or Solvent Base Liquids
-----------------------------	--

Absorbency Capacity	131 l per bale (saturated; medium viscosity- 12.6x)
----------------------------	---

Packaging Description:

Package configuration	Bale	Pkg. Weight	9.2 kg (9.0 kg)
Items per Package	10 Booms/Bale	Pkg. Dimensions (approx.)	60cm dia. x 65cm H
Container type	Polybag + Twist-tie		

Physical Properties:

<u>Parameter</u>	<u>SPC Test Method</u>	<u>Units</u>	<u>Nominal</u>	<u>(+/-)Tolerance</u>
Boom Weight	Gravimetric	kg	0.9	0.09
Absorbency** (med. oil)	SPCTM-012B	gL/gS	12.6	11-min.
Color	Visual	-----	White	per standard
Netting Tensile Strength	-----	daN	1134	per specification

The above properties are "nominal" values used for PROCESS CONTROL when the product is produced and/or inspected. Performance "nominals" may vary depending upon the specific application, and/or the environment being applied, stored, or shipped.

**** The "Absorbency" Spec and "SPCTM012" test method is based on the protocol of ASTM F726, using SAE20 non-detergent as the Oil Type, medium viscosity.**

Attributes	Product will be free of foreign material contamination, rips, holes, and tears.
Labeling	Each package to be clearly labeled with Company Name, Address, Item No., Date, and/or Package Code (Bar Code).
Certification	Make no changes in basic process or composition without notifying customer. Claims for non-conformance of goods must be made within 60-days of delivery.