



GENERAL PRODUCT SPECIFICATION

Item No.	UXT200-E
-----------------	----------

Date	16-6-2017	Replaces	4-11-11	No. Pages	1
-------------	-----------	-----------------	---------	------------------	---

Product Description:

Style	Pads ; perforated on centerline for dividing in half for smaller applications
Item Size (each)	41 cm x 51 cm
Color	Dark Gray
Composition	Polypropylene >98%, Surfactant < 1.0%, color pigment < 1.0 %
Structure	A nonwoven mat where the middle ply is made of randomly oriented Micro-fibers [2-10 micron diameters] and the coverstock layers are lint-resistant & abrasion resistant {controlled porosity} spunbond nonwoven of continuous filaments randomly oriented and thermally point bonded [15-30 micron diameters].
Technology	Meltblown and Spunbond, 3-ply
Absorbency	Universal (Hydrophilic + Oleophilic)
Bonding	Bonded (staggered pattern) + Mechanical entanglement

Intended Application	Low -Lint Chemical Resistant Sorbent for Water, Oil, or Solvent Base Liquids
-----------------------------	--

Absorbency Capacity	145 l. per bale (saturated; medium viscosity-15x)
----------------------------	---

Packaging Description:

Package configuration	1-Case	Pkg. Weight	9.3 kg (8.4 kg)
Items per Package	200-Pads/Case	Pkg. Dimensions	53 cm x 43 cm x 54 cm (H)
Container type	Carton		

Physical Properties;

<u>Parameter</u>	<u>SPC Test Method</u>	<u>Units</u>	<u>Nominal</u>	<u>(+/-)Tolerance</u>
Basis Weight	SPCTM-002A	G/M2	200	20
Caliper	SPCTM-020	mm	3.3	0.3
Absorbency** (med. Oil)	SPCTM-004B	gL/gS	15	2
Tensile Strength	SPCTM-007	daN	30	3
Color	Visual	-----	Dark Gray	per standard

The above properties are “nominal” values used for PROCESS CONTROL when the product is produced and/or inspected. Performance “nominals” may vary depending upon the specific application, and/or the environment being applied, stored, or shipped.

**** The "Absorbency" Spec and "SPCTM004" test method is based on the protocol of ASTM F726, using SAE20 non-detergent as the Oil Type, medium viscosity.**

Attributes	Product will be free of foreign material contamination, rips, holes, and tears.
Labeling	Each package to be clearly labeled with Company Name, Address, Item No., Date, and/or Package Code (Bar Code).
Certification	Make no changes in basic process or composition without notifying customer. Claims for non-conformance of goods must be made within 60-days of delivery.